

Throughout this manual, there are a number of HAZARD WARNINGS that must be read and adhered to in order to prevent possible personal injury and/or damage to equipment. Two signal words "WARNING" and "CAUTION" are used to indicate the severity of a hazard and are preceded by the safety alert symbol.



WARNING

Used when serious injury or death MAY result from misuse or failure to follow specific instructions.



CAUTION

Used when minor or moderate injury or product / equipment damage MAY result from misuse or failure to follow specific instructions.



NOTICE

Indicates information considered important, but not hazard-related.

SAFETY INSTRUCTIONS

Indicates specific safety-related instructions or procedures.

It is the responsibility of all personnel involved in installation, operation and maintenance to fully understand the

 Warning and  Caution procedures by which hazards are to be avoided.


MODELS

TCPE, WPB, WPD

Twin City Fan & Blower Catalogs 4800 and 4820 provide additional information on this equipment. These catalogs can be found at www.tcf.com or by contacting your local Twin City Fan & Blower sales representative.



TCPE



WPB



WPD

RECEIVING, UNPACKING & INSPECTION

When the equipment is received all items should be carefully checked against the bill of lading to be sure all crates and cartons have been received. Before accepting delivery, carefully inspect each carton or crate for visible shipping damage. If any damage is noticed, the carrier should make the proper notation on the delivery receipt acknowledging the damage. Make notations of all damage on all copies of the bill of lading and have all copies countersigned by the delivering carrier. The carrier should also fill out a Carrier Inspection Report. The factory Traffic Department should then be contacted. File claim for damage with the carrier. Physical damage to the unit after acceptance is not the responsibility of Twin City Fan Companies, Ltd.

Unpack each carton or crate and verify that all required parts and proper quantities of each item have been received. Refer to drawings for part descriptions. Report shortages or missing items to your local representative to arrange for replacement parts.

Due to availability of carriers and truck space, it is not possible to guarantee that all items will be shipped together. Verification of shipments must be limited to only those items on the bill of lading.

NOTICE

The unit nameplate must be checked to make sure the voltage agrees with the power supply available.



CAUTION

Sheet metal parts, screws, clips and similar items inherently have sharp edges, and it is necessary that the installer and service personnel exercise caution.

The installation of this equipment shall be in accordance with the regulations of authorities having jurisdiction and all applicable codes. This equipment is to be installed by an experienced installation company and fully trained personnel. The mechanical installation of the exhaust ventilator consists of making final connections between the unit and building services, duct connections.

STORAGE

If fans are stored for any length of time, they should be stored in a clean, dry location to prevent rust and corrosion. Outdoor storage is not recommended. When outdoor storage is necessary, fans should be protected from the elements as completely as possible. Cover the fan inlet and outlet and keep motors dry and clean.

For extended storage (more than 3 months) motor shafts and bearings should be rotated monthly. If stored longer than 6

months, bearing grease in motor and fan should be purged and replaced with compatible grease. Belts should be rechecked for proper tension. Storage records should be kept to assure proper maintenance. The factory can advise warranty centers to provide motor and bearing service if needed.

LIMITATION OF WARRANTIES AND CLAIMS

Seller warrants to the original purchaser that the goods sold hereunder shall be free from defects in workmanship and material under normal use and service (except in those cases where the materials are supplied by the buyer) for a period of one year from the date of original installation or eighteen (18) months from the date of shipment, whichever occurs first. The liability of seller under this warranty is limited to replacing, repairing or issuing credit (at cost, F.O.B. factory and at seller's discretion) for any part or parts that are returned by buyer during such period provided that:

- Seller is notified in writing within ten (10) days following discovery of such defects by buyer, or within ten (10) days after such defects should reasonably have been discovered, whichever is less;
- The defective unit is returned to seller, transportation charges prepaid by buyer;
- Payment in full has been received by seller or said products;
- Seller's examination of such unit shall disclose to its satisfaction that such defects have not been caused by misuse, neglect, improper installation, repair, alteration, act of God or accident.

No warranty made hereunder shall extend to any seller product whose serial number is altered, effaced or removed. Seller makes no warranty, express or implied, with respect to motors, switches, controls or other components of seller's product, where such components are warranted separately by their respective manufacturers. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, WHETHER STATUTORY OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. In no event shall seller be liable to buyer for indirect, incidental collateral or consequential damages of any kind. (BUYER'S FAILURE TO PAY THE FULL AMOUNT DUE WITHIN SIXTY (60) DAYS OF DATE OF INVOICE SHALL OPERATE TO RELEASE SELLER FROM ANY AND ALL LIABILITY OR OBLIGATION ARISING PURSUANT TO ANY WARRANTY, EXPRESS OR IMPLIED, WHETHER STATUTORY OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, MADE IN CONNECTION WITH ANY CONTRACT FORMED HEREUNDER. BUYER AGREES THAT SUCH FAILURE TO PAY SHALL CONSTITUTE A VOLUNTARY WAIVER OF ANY AND ALL SUCH WARRANTIES ARISING PURSUANT TO SUCH CONTACT.)

ELECTRICAL CONNECTION

1. Connect supply wiring to a disconnect switch. Check the wiring diagrams on the motor for connections.
2. The motor is factory set at the voltage marked on the fan nameplate. Check the line voltage with the nameplate voltage and wiring diagrams.
3. The main power wiring should be sized for the ampacity shown on the nameplate. Size wires in accordance with the ampacity tables in Article 310 of the National Electrical Code. If long wires are required, it may be necessary to increase wire size to prevent excessive voltage drop. Wires should be sized for a maximum of 3% voltage drop.



CAUTION

Use copper conductors only.

Protect wiring from sharp edges. Leave some slack in the line to prevent damage.

4. (Optional) Disconnect switches are not fused. The **power leads must be protected** at the point of distribution in accordance with the fan nameplate.

5. On fans without a thermal protector integral to the motor (refer to unit or motor nameplate to determine if protector is present) a separate overload device is required. Refer to Sections 430-32 of the N.E.C. for sizing.
6. All units must be electrically grounded in accordance with local codes or, in the absence of local codes, with the latest edition of the National Electrical Code (ANSI/NFPA 70). **A ground lug is provided as standard in the unit terminal box.** Size grounding conductor in accordance with Table 250-95 of the National Electrical Code. **DO NOT** use the ground lug for connecting a neutral conductor.
7. Supply voltage to the power ventilator should not vary by more than 10% of the value indicated on the unit nameplate. Phase unbalance must not exceed 2%.



WARNING

Failure of motor due to operation on improper line voltage or with excessive phase unbalance constitutes product abuse and may cause severe damage to the unit's electrical components.

CHECK, TEST & START PROCEDURE



WARNING

Electric shock hazard. Could cause severe injury or death. Failure to bond the frame of this equipment to the building electrical ground by use of the grounding terminal provided or other acceptable means may result in electrical shock. Disconnect electric power before servicing equipment. Service to be performed only by qualified personnel.



WARNING

Especially check three-phase units for rotation. For three-phase, rotation can be changed by interchanging any two of the three line leads. If unit is checked on temporary wiring, it should be rechecked when permanently installed. Motor burn-out or tripped overload protection devices are usually the result of wrong rotation.

SAFETY INSTRUCTIONS

BEFORE START-UP: Disconnect power to this unit before servicing the unit.

1. Check to verify that the impeller is free to rotate.
2. Verify that supply voltage on the line side of disconnect agrees with voltage on fan data plate and is within the 10% utilization voltage.
3. Apply power to unit and check rotation of impeller with the directional arrow on the unit.



WARNING

Rotation is critical. If allowed to operate in the wrong direction, the motor will overload and burn out.

4. **Electrical Input Check:** Perform check of fan ampere draw and verify that motor nameplate amps are not exceeded. Take into account the service factor range if motor is nameplated above a 1.0 service factor.
5. Fan RPM should be checked and verified with a tachometer.
6. **Units with Speed Control (TCPE):** Verify that speed controller gives desired operating range of RPM. If minimum speed value is not desired, it may be adjusted. See page 4.

NOTICE

The fan was balanced at the factory to be within stringent vibration levels before shipment. However, there are several things that may cause vibration, such as rough handling in shipment and installation, weak foundations and alignments.

SPEED CONTROL INSTALLATION

(MODEL TCPE - OPTIONAL)

The controller is designed to start the motor at high speed and will then slow down. This gives the motor good starting characteristics.

Speed control is available using **115/60/1 open** type PSC or shaded pole motors.

INSTALLATION

Connect control in series with motor and line voltage (**115V only**). Never connect across line. See Figure 1.

MINIMUM SPEED SETPOINT

All controls are factory set to 65V±3V output as standard with an input voltage of 120V. If different minimum speed is desired, the control may be adjusted by turning minimum speed pot clockwise to decrease minimum speed and counterclockwise to increase minimum speed. Refer to Figure 2.

WARNING

If minimum speed is readjusted, verify unit ampere draw does not exceed motor nameplate amps. Do not operate unit in range where amp draw exceeds motor nameplate.

CAUTION

These motors operate more efficiently in the ranges set from the factory. Operating motor outside these ranges (see Table 2) may cause motor to run hotter and substantially shorten motor life.

NOTICE

Lowering the minimum speed setpoint may adversely affect motor start-up characteristics.

WARNING

Certain failure modes of solid-state controls such as half-waving can cause high levels of DC, motor overheating and motor burn-out. Therefore, a thermal overload protection (integral with motor) is required to limit the maximum motor temperature under such a failure.

NOTICE

Do not allow any sleeve bearing motor to operate below 500 RPM. Operation below 500 RPM will substantially shorten bearing life.

Figure 1. Connection Diagram, Speed Control




Table 2. Speed Controller RPM Range

HP	RPM	MAX. RPM	MIN. RPM
1/8	1650/1500/1350 ^{2,3}	1650 ⁴ 1500 ⁵	1300 ⁴ 950 ⁵
1/8	860	860	500
1/6			
1/4			
1/2			
1/6	1140	1140	900
1/4			
1/2			
1			
1/3	1725	1725	1200
1/2			
3/4			


NOTES:

- Speed control available only with 115/60/1 open motors (thermally protected).
- Three-speed motor (multiple tap winding).
- Speed control should not be connected to low speed tap on motor because of starting characteristics.
- Speed control connected to high speed tap on motor.
- Speed control connected to medium speed tap on motor.

Table 1. Speed Controller Size

MOTOR			SPEED CONTROLLER DESIGNATION / FLA		
HP	RPM	VOLTAGE	KBWC-15K 5 AMP	KBWC-110 10 AMP	KBWC-115 15 AMP
1/8	1650/1500/ 1350	115V	X		
1/8	860	115V	X		
1/6	860	115V	X		
1/4	860	115V	X		
1/2	860	115V		X	
1/6	1140	115V	X		
1/4	1140	115V	X		
1/2	1140	115V		X	
1	1140	115V			X
1/3	1725	115V		X	
1/2	1725	115V		X	
3/4	1725	115V			X

Figure 2. Low End Setpoint Adjustment



NOTE: For TCPE fans using Electronically Commutated (EC) Motors, refer to **IM-4055**.

PANEL INSTALLATION (WITHOUT COLLAR) — TCPE

1. The TCPE panel fan is an axial exhauster that can be mounted either vertically or horizontally. Figure 3 depicts a typical wall installation.
2. A typical frame is usually roughed in so that the inside square dimension is approximately $\frac{1}{2}$ " to $\frac{3}{4}$ " more than what the fan panel measures. If using the optional wall collar the frame should be $\frac{3}{4}$ " to 1" more than what the fan panel measures.
3. Place the unit into the frame with the wiring hole A in the position that is most suitable for wire to enter the unit. Fasten the unit to the frame through the holes provided using lag bolts. If the electrical wire will be coming from within the wall that the TCPE is being mounted to, run the wire through hole A by entering it from the orifice side of the panel. This should be done before the panel is fastened to the frame to reduce the need of disassembly. If the wiring is not done during the installation the motor and guard can be removed from the panel fan without having to actually remove the panel itself. See Figure 3. Make sure a strain relief is attached to the wires after the wire is pulled into position.


CAUTION

Use copper conductors only.

Protect all wires from sharp edges. Do not route wire through wiring hole without a strain relief to protect it.


4. Connect the electrical wire to a disconnect switch and then connect the wire to the motor (an optional speed control may be installed in series with a 115V ODP motor and disconnect switch). See Figure 1 on Page 4. The wiring diagram for the motor is on a label attached to the motor. Main power wiring should be sized for the amperage shown on the data plate attached to the fan panel.
5. Disconnect switches (Optional) are not fused; therefore, **the power leads must be protected** at the point of distribution in accordance with the unit data plate.
6. All TCPE motors are thermally protected. All units must be electrically grounded in accordance with local codes or in accordance with the NEC. A grounding point is provided with all motors and will be described on the wiring diagram that is attached to the motor.
7. Supply voltage to the motor should not vary by more than 10% of the value indicated on the unit data plate. Phase unbalance must not exceed 2%.


WARNING

Failure of the unit due to improper line voltage or excessive phase unbalance constitutes product abuse. Severe damage to the unit's electrical components may occur.

8. Make sure unit is properly sealed around the frame edges so that the outside elements cannot enter the building.

Figure 3. Typical Installation




TCPE SIZE	PANEL SQ.	WALL OPENING	DAMPER SIZE	'M' (MIN.)
8	13.25	13.75	10 x 10	14.0
10	15.25	15.75	12 x 12	
12	18.25	18.75	15 x 15	
14	21.25	21.75	18 x 18	14.0
16	23.25	23.75	20 x 20	
18	25.25	25.75	22 x 22	
20	27.25	27.75	24 x 24	14.0
24	30.25	30.75	27 x 27	

WALL OPENING REQUIREMENTS

Wall opening size and the distance between impeller and damper are two important dimensions for fan installation. Fans mounted in or to the wall require a different wall opening size than those mounted in collars. Impeller-to-damper distance (M) is important to reduce turbulence at the damper, which may lead to premature damper failure, and to prevent the impeller blades from hitting the actuator on motorized damper units.

Figure 4. Fan Assembly Without a TCPE Wall Collar




PANEL INSTALLATION (WITHOUT ACCESSORIES) — WPB & WPD

WALL OPENING REQUIREMENTS

Wall opening size and the distance between impeller and damper are two important dimensions for fan installation. Fans mounted to the wall require a different wall opening size than those mounted in collars or wall boxes. Impeller-to-damper distance (M) is important to reduce turbulence at the damper, which may lead to premature failure and to prevent the impeller blades from hitting the actuator on motorized damper units. Use general installation procedure from page 5.


To achieve the minimum 'M' dimension, this installation requires a spacer (by others) between the fan and the wall.

If the wall is equal to or greater than the minimum 'M' dimension, the fan can be mounted directly to the wall.




IMPELLER SIZE	PANEL SQ.		WALL OPENING (MIN.)				DAMPER SIZE		'M' (MIN.)
			SURFACE MOUNT		RECESS (IN WALL)				
	WPB	WPD	WPB	WPD	WPB	WPD	WPB	WPD	
14	--	17.00	--	14.50	--	17.50	--	14 x 14	16.00
16	--	20.00	--	17.50	--	20.50	--	17 x 17	
18	--	22.00	--	19.50	--	22.50	--	19 x 19	
21	25.00	25.00	22.50	22.50	25.50	25.50	22 x 22	22 x 22	16.00
24	28.00	28.00	25.50	25.50	28.50	28.50	25 x 25	25 x 25	
30	36.00	36.00	33.50	33.50	36.50	36.50	33 x 33	33 x 33	
36	42.00	42.00	39.50	39.50	42.50	42.50	39 x 39	39 x 39	16.00
42	48.00	48.00	45.50	45.50	48.50	48.50	45 x 45	45 x 45	
48	54.00	54.00	51.50	51.50	54.50	54.50	51 x 51	51 x 51	
54	60.00	--	57.50	--	60.50	--	57 x 57	--	19.00
60	66.00	--	63.50	--	66.50	--	63 x 63	--	


WALL COLLAR WITH ACCESSORIES — TCPE



WALL COLLAR WITH ACCESSORIES — WPB, WPD





WALL BOX WITH ACCESSORIES — WPB, WPD





MOUNTING ARRANGEMENTS — WITH WALL COLLAR OR WALL BOX



FLUSH WITH OUTSIDE WALL



MIDDLE OF WALL



FLUSH WITH INTERIOR WALL



WALL COLLAR, WALL BOX HOUSINGS

The wall collar and wall box are intended to give the panel fan an easy way to adapt other accessories for a completed unit. They are set up to accept a panel fan, damper and weather hood or a damper guard screen. All holes are pre drilled for the fan and accessories to help make the installation easy.

WALL COLLAR INSTALLATION

1. If the collar is ordered as a field assembly, assemble it first by following the directions provided with the kit.
2. When roughing in the frame make the inside dimension $\frac{1}{2}$ " to $\frac{3}{4}$ " larger than the outside dimension of the collar. This will give the collar enough clearance so that it will install easily.
3. Predrill holes into the collar wherever it is decided that it can be fastened to the roughed-in frame. The wall collar can be fastened to a roughed-in frame with lag screws through holes that need to be drilled into the collar. It is recommended that two lag screws per collar side be used to fasten it to the frame and that the bent edge of the collar is flush with the outside wall.
4. If power is coming into the unit from within the wall a $\frac{3}{4}$ " to 1" hole may also have to be drilled for the power wire to enter the collar. Be sure the metal edges of the hole are protected so the wire will not get cut.
5. If a damper, weather hood or damper guard screen are being used, they can be fastened to the collar before the collar is fastened to the frame.
6. Make sure the edges around the collar and frame are sealed after it is installed.

The **wall box** is installed in the same way.

TCPE SIZE	COLLAR SQ.	WALL OPENING
8	13.50	14.25
10	15.50	16.25
12	18.50	19.25
14	21.50	22.25
16	23.50	24.25
18	25.50	26.25
20	27.50	28.25
24	30.50	31.25

WPB/WPD SIZE	COLLAR/WALL BOX SQ.		WALL OPENING	
	WPB	WPD	WPB	WPD
14	--	17.25	--	18.00
16	--	20.25	--	21.00
18	--	22.25	--	23.00
21	25.25	25.25	26.00	26.00
24	28.25	28.25	29.00	29.00
30	36.25	36.25	37.00	37.00
36	42.25	42.25	43.00	43.00
42	48.25	48.25	49.00	49.00
48	54.25	54.25	55.00	55.00
54	60.25	--	61.00	--
60	66.25	--	67.00	--

WEATHER HOOD AND DAMPER GUARD SCREEN

The weather hood and damper guard screen are both items designed to help protect the damper from damage and keep birds and other things from entering the building. The weather hood will help deflect the outside elements from entering into the building through the fan. It also helps protect the damper from being inappropriately operated by the wind.

WEATHER HOOD AND DAMPER GUARD SCREEN INSTALLATION

1. If mounting the damper guard screen or weather hood onto a wall collar place it over the damper and use the self-tapping screws provided with the collar to fasten it through the pre drilled holes in the collar's bent edge.
2. Make sure any undesired gaps are sealed to keep the elements from leaking into the building.

MAINTENANCE

Installation and maintenance are to be performed only by qualified personnel who are familiar with local codes and regulations and experienced with this type of equipment.



CAUTION

Sharp edges and screws are a potential injury hazard. Avoid them.



WARNING

Hazardous moving parts. Unit may contain protected fan motor, which may start automatically and cause injury. Allow time for reset. Disconnect power before servicing.

Preventive maintenance is the best way to avoid unnecessary expense and inconvenience. Start-up and routine maintenance should cover the following items:

- Tighten all set screws, bolts and wire connections.
- Check belt tension and sheaves for wear.
- Lubricate fan bearings (see Tables 3 and 4).
- Cleaning of unit, impeller and damper (if present).

All motors containing ball bearings are permanently lubricated from the factory. No additional maintenance is required.

- Before performing any maintenance on the fan, be sure power is turned off and locked in the OFF position at the service entrance.
- Ventilators should be carefully checked at least once a year. For critical or rugged applications, a routine check every two or three months is suggested.
- All motors supplied with Twin City Fan & Blower ventilators carry a one-year limited warranty from date of shipment. For repairs within the warranty period, the motor must be taken to the motor manufacturer's authorized service dealer. Contact your representative for additional warranty details.
- A periodic motor check should consist of spinning the motor shaft with the power off to be sure the motor turns freely and the bearings run smoothly. The belt on belt driven units should be removed from the motor sheave.
- When removing or installing a belt, do not force the belt over the sheave. Loosen the motor mount so that the belt can be easily slipped over the sheave.
- The belt on belt driven units should be removed and carefully checked for glazing, cracks, ply separation or irregular wear. A small irregularity in the contact surface of the belt will result in noisy operation. If any of these defects are apparent, the belt should be replaced. Check the sheaves also for chipping, dents or rough surfaces, which could damage the belt.

- The correct belt tension is important. Too tight of a belt will result in excess bearing pressure on the motor bearings and shaft pillow blocks and may also overload the motor. Too loose of a belt will result in slippage, which will quickly "burn" out belts. A belt should feel "live" when thumped, approximately $\frac{1}{4}$ " belt deflection (3 to 5 lb.) when subject to finger pressure at midpoint between sheaves.
- The belt alignment should also be checked to be sure the belt is running perpendicularly to the rotating shafts. Fan and motor shafts must be parallel. Improper alignment will result in excessive belt wear.
- Check sheave set screws to ensure tightness. Proper keys must be in keyways.
- For blade angle adjustments on Type 'E' impellers (Level 3) refer to Installation & Maintenance Manual IM-404.
- If unit is to be left idle for an extended period, it is recommended that belts be removed and stored in a cool, dry place to avoid premature belt failure.
- The standard pillow block bearings on belt driven ventilators are factory lubricated and are provided with external grease fittings. Annual lubrication is recommended or more frequently if needed (see Table 3).

It is recommended to add fresh grease at start-up, but do not over-grease. Use only 1 or 2 shots of a recommended lubricant with a hand gun in most cases (see Table 4). Maximum hand gun rating 40 P.S.I. Rotate bearings during lubrication where good safety practice permits.



CAUTION

Greases of different soap bases (lithium, sodium, etc.) may not be compatible when mixed. Prevent such intermixing by completely purging the bearing of old greases.

The most frequent causes of bearing failure are not greasing often enough, using an excessive quantity of grease or using incompatible greases. Excessive vibration, especially if the bearing is not rotating, will also cause bearings to fail. Bearings must also be protected from water and moisture to avoid internal corrosion.

- During the first few months of operation it is recommended that the bearing set screws be checked periodically to ensure that they are tight.
- The rotating impeller requires particular attention since materials in the air being handled can build up on the blades to cause destructive vibration or weaken the structure of the impeller by corroding and/or eroding the blade metal. Regular inspection and corrective action at intervals determined by the severity of each application are essential to good service life and safety.

Table 3. Suggested Fan Bearing Greasing Intervals

INTERVAL (MONTHS)	TYPE OF SERVICE
12 to 18	Infrequent operation or light duty in clean atmosphere
6 to 12	8 to 16 hrs./day in clean, relatively dry atmosphere
3 to 6	12 to 24 hrs./day, heavy-duty or if moisture is present
1 to 3	Heavy-duty in dirty, dusty locations; high ambient temperatures; moisture-laden atmosphere; vibration

Table 4. Grease Manufacturers

MANUFACTURER	GREASE (NLGI #2)
Shell	Gadus S2 V100 2
Exxon/Mobil	Ronex MP

BEARING REPLACEMENT

Fan bearings on belt driven fans should not need to be replaced for many years if the previous recommendations are strictly adhered to. However, use the following procedure when bearing replacement is necessary.

1. Gain access to the fan bearings. Remove the bearing cover, if any.
2. Loosen the belts by shifting the motor.
3. Remove the impeller and disconnect the remote lubrication tubes (if applicable).
4. Measure the location of the bearing to the impeller end of the shaft and the bearing spacing.
5. Remove the shaft and bearing assembly. Note the position of the bearings' shims (if applicable).
6. Loosen all bearing/shaft set screws or other locking devices.
7. Remove bearings (may need to be pressed off the shaft).
8. Polish the shaft with fine emery paper (240 grit or finer) and file the setscrew dimples left on the shaft flat.
9. Install new bearings on the shaft, making sure that the collars are together (i.e. facing each other on the shaft). Lightly seat one setscrew or eccentric locking collar on each bearing to hold in the approximate marked position.
10. Mount the shaft/bearing assembly in the fan with bolts. Do not tighten yet. Just snug up. Loosen the setscrew.
11. Center the shaft in the housing (both ends) as closely as possible. (The fan impeller may need to be temporarily installed to get its clearances equal.)
12. Tighten the bearing mounting bolts.
13. Reinstall the lube tubes (if applicable).
14. Install impeller and belts and adjust the motor to get proper belt tension. Also, make sure that the sheaves are properly aligned.
15. If a new shaft is supplied, ignore items 6 thru 8.

MOTORS

Twin City Fan & Blower recommends periodic checks of voltage, frequency and current of a motor while in operation. Such checks assure the correctness of frequency and voltage applied to the motor, and yield an indication of the fan load. Comparison of this data with previous data will give an indication of the fan performance. Any serious deviations could indicate a potential motor failure.

All motors have pre lubricated sealed bearings and are lubricated for the life of the motor.

1. All motors carry a one-year limited warranty from date of shipment. For repairs within the warranty period, the motor must be taken to the motor manufacturer's authorized service dealer. Contact your representative for additional warranty details.

2. A periodic motor check should consist of spinning the motor shaft with the power off to be sure the motor turns freely and the bearings run smoothly. The belt on belt driven units should be removed from the motor pulley.

Repair or replacement of motors is normally performed by a repair station authorized by the manufacturer. Contact your representative or the factory for locations nearest you. DO NOT ship motor to the factory without specific authorization forms.

V-BELTS

V-belts on these belt driven fans are oil, heat and static resistant type and oversized for continuous-duty. With proper installation and maintenance, years of operating efficiency can be added to the lifespan of the V-belt drive.

The condition of V-belts and the amount of belt tension should be checked prior to start-up (see Figure 5). When it becomes necessary to adjust belt tension, do not over-tension as bearing damage will occur. Recommended belt tension should permit $\frac{1}{64}$ " deflection per inch of span of the belt at the center of the belt span. To find this point, measure halfway between the pulley centerlines as shown in Figure 6. Extreme care must be exercised when adjusting V-belts as not to mis-align the pulleys. Any misalignment will cause a sharp reduction in belt life and will also produce squeaky, annoying noises (see Figure 7). On units equipped with 2 groove pulleys, adjustments must be made so that there is equal tension on all belts (see Figure 9).

1. Where tensioning rods are not available, adjustment is more easily obtained by loosening and adjusting one side of the motor bracket at a time.
2. Always loosen tension adjustment enough to place belts on sheaves without running belts over the edge of either sheave. A new belt may be seriously damaged internally by careless handling (see Figure 8).



WARNING

When removing or installing belts, never force belts over pulleys without loosening motor first to relieve belt tension.

3. Fan speed can be increased by closing the adjustable motor pulley or decreased by opening it. Two and three groove adjustable pitch pulleys must be adjusted an equal number of turns. (See Figure 9). Always check load on motor when increasing fan speed.

Figure 5. Eliminate Slack




Figure 6. Belt Deflection





Figure 7. Alignment



Mount belts straight. Shafts must be parallel and sheaves in alignment to prevent unnecessary belt wear.

Figure 8. Belts





Figure 9. Two-Groove Sheaves



FAN TROUBLESHOOTING CHART

PROBLEM	POSSIBLE CAUSES
FAN DOES NOT OPERATE	<ol style="list-style-type: none"> 1. Wrong voltage. 2. Electricity turned off or not wired properly. 3. Tripped overload protector. 4. Blown fuses. 5. Loose pulleys. 6. Broken belts.
TOO LITTLE AIR	<ol style="list-style-type: none"> 1. Impeller rotating in wrong direction. 2. Fan speed lower than design. 3. System is more restrictive (more static pressure) than expected. 4. Restricted fan inlet or outlet. 5. Inlet or outlet screens clogged. 6. Filters, if applicable, are dirty or clogged.
TOO MUCH AIR	<ol style="list-style-type: none"> 1. Fan speed higher than design. 2. System is less restrictive (less static pressure) than expected. 3. Filters, if applicable, not in place.
EXCESSIVE HORSEPOWER	<ol style="list-style-type: none"> 1. Impeller rotating in wrong direction. 2. Impeller rubbing on inlet venturi. 3. Fan speed higher than design. 4. Worn fan bearings.
EXCESSIVE NOISE	<ol style="list-style-type: none"> 1. Impeller or sheaves loose. 2. Bearing or drive misalignment. 3. Accumulation of material on impeller. 4. Worn or corroded impeller. 5. Impeller out of balance. 6. Impeller hitting housing. 7. Bent shaft. 8. Bearings need lubrication. 9. Loose bearing bolts. 10. Loose or worn bearings. 11. Mismatched belts. 12. Belts too loose or too tight. 13. Belts oily or dirty. 14. Belts worn. 15. Loose fan mounting bolts. 16. Rattle of components in high velocity airstream. 17. Electrical noise. 18. Noise from high velocity air system. 19. Vibrating parts not isolated from building. 20. Vibrating ductwork.
EXCESSIVE VIBRATION	<ol style="list-style-type: none"> 1. Impeller or sheaves loose on shaft. 2. Impeller out of balance. 3. Excessive buildup of dirt/dust on impeller. 4. Belts too loose or too tight. 5. Mismatched belts. 6. Bent shaft. 7. Bearing or drive misalignment. 8. Loose or worn bearings. 9. Fan mounting bolts loose. 10. Structures not cross-braced.

It is recommended that the users and installers of this shipment familiarize themselves with AMCA Publication #201, "Fans and Systems" and Publication #202, "Troubleshooting," which are published by the Air Movement and Control Association (AMCA), 30 West University Drive, Arlington Heights, Illinois 60004. www.amca.org

MODEL NOMENCLATURE

TCP E-14-2 A

Model TCPE, Direct Drive

E = Exhaust

Impeller Diameter

Design Vintage / Motor Type

A = Design A

AE = Design A with EC Motor

Speed

0 = 800 or 1350 RPM

1 = 1100 or 1500 RPM

2 = 1700 or 1650 RPM

WPB-E-24-B-1-05-25

Model

WPD = Wall Mounted Fan, Direct Drive

WPB = Wall Mounted Fan, Belt Driven

E = Exhaust, S = Supply

Fan Size

Impeller Type

L1 & L2 = Level 1 & Level 2, Fabricated Steel, Fixed Pitch (5-Bladed)

B = Cast Aluminum, Adjustable Pitch (4, 5, and 6-Bladed)

E = Cast Aluminum, Adjustable Pitch (4 and 8-Bladed)

C = Cast Aluminum, Adjustable Pitch (4 and 6-Bladed)

Z = Fabricated Steel, Fixed Pitch (5-Bladed)



Hub Designation (B Impellers Only)

No. of Blades


Impeller Blade Angle (B, C, E and Z Impellers Only)

DIMENSIONAL DATA

TCPE – DIRECT DRIVE



EXHAUST AIRFLOW




SUPPLY AIRFLOW

TCPE SIZE	A I.D.	B I.D.	C	D QTY.	F	R RAD.	X MAX.	Y MAX.	PROP. DIA.	DAMPER SIZE	WALL OPENING SQ. MIN.	MOTOR FRAME
080A, 081A, 082A, 082AE	13.25	8.38	1.25	8	4.00	0.75	10.25	12.25	8.00	10 x 10	13.75	48
100A, 101A, 102A, 102AE	15.25	10.38	1.50		5.00	0.75	11.25	13.25	10.00	12 x 12	15.75	
120A, 121A, 122A, 122AE	18.25	12.38	2.00		6.50	0.875	11.50	13.50	12.00	15 x 15	18.75	
140A, 141A, 142A, 142AE	21.25	14.50	2.75	12	8.00	1.00	19.00	21.00	14.00	18 x 18	21.75	56C
160A, 161A, 162A, 162AE	23.25	16.50	3.00		9.00	1.13	19.00	21.00	16.00	20 x 20	23.75	
180A, 181A, 182A, 182AE	25.25	18.50	3.00		10.00	1.25	19.00	21.00	18.00	22 x 22	25.75	
200A, 201A, 202A, 202AE	27.25	20.63	3.00		11.00	1.50	20.50	22.50	20.00	24 x 24	27.75	
240A, 241A, 242A, 242AE	30.25	24.63	3.00		12.00	1.50	22.00	24.00	24.00	27 x 27	30.75	

D4800E
D4805

DIMENSIONAL DATA


WPD – DIRECT DRIVE



WPD SIZE	A	B	C SQ.	D MAX		DAMPER SIZE	MAX MOTOR FRAME
				EXHAUST	SUPPLY		
14	14.25	2.75	17.00	11.18	14.88	14 x 14	56
16	16.25	3.00	20.00	11.18	14.88	17 x 17	56
18	18.25	3.00	22.00	11.18	14.88	19 x 19	56
21	21.25	3.50	25.00	14.41	17.36	22 x 22	145T
24	24.25	3.50	28.00	14.55	17.36	25 x 25	184T
30	30.38	4.00	36.00	14.74	19.05	33 x 33	184T
36	36.38	5.00	42.00	15.67	19.93	39 x 39	215T
42	42.38	5.50	48.00	23.59	30.00	45 x 45	254T
48	48.38	6.00	54.00	23.59	30.00	51 x 51	254T

D4810-12A
D4810-13A

WPB – BELT DRIVEN, LEVELS 1 & 2




WPB SIZE	A	B	C SQ.	D MAX				DAMPER SIZE	MAX MOTOR	
				EXHAUST		SUPPLY			FRAME	
				L1	L2	L1	L2		L1	L2
21	21.25	3.50	25.00	14.19	14.19	20.00	20.00	22 x 22	56	145T
24	24.25	3.50	28.00	14.38	14.38	20.78	20.78	25 x 25	56	145T
30	30.38	4.00	36.00	15.68	17.06	22.63	24.25	33 x 33	145T	184T
36	36.38	5.00	42.00	16.25	17.44	22.75	24.32	39 x 39	145T	184T
42	42.38	5.50	48.00	16.44	17.94	23.57	25.00	45 x 45	145T	184T
48	48.38	6.00	54.00	17.06	18.44	24.75	26.32	51 x 51	145T	184T
54	54.38	6.50	60.00	17.13	18.44	25.44	26.94	57 x 57	145T	184T
60	60.38	7.25	66.00	17.44	22.68	26.44	31.82	63 x 63	145T	215T

D4820-12A
D4820-13A


DIMENSIONAL DATA

WPB – BELT DRIVEN, LEVEL 3, SIZES 21-36



WPB SIZE	A	B	C SQ.	D MAX		DAMPER SIZE	MAX MOTOR FRAME
				EXHAUST	SUPPLY		
21	21.25	3.50	25	17.25	20.50	22 x 22	145T
24	24.25	3.50	38	17.25	20.50	25 x 25	145T
30	30.38	4.00	36	18.31	20.93	33 x 33	184T
36	36.38	5.00	42	18.31	21.93	39 x 39	184T

WPB – BELT DRIVEN, LEVEL 3, SIZES 42-60



WPB SIZE	A	B	C SQ.	D MAX		DAMPER SIZE	MAX MOTOR FRAME
				EXHAUST	SUPPLY		
42	42.38	5.50	48	21.31	26.75	45 x 45	215T
48	48.38	6.00	54	21.31	26.75	51 x 51	215T
54	54.38	6.50	60	26.13	32.30	57 x 57	254T
60	60.38	7.25	66	26.13	32.30	63 x 63	256T



TWIN CITY FAN & BLOWER | WWW.TCF.COM

5959 TRENTON LANE N. | MINNEAPOLIS, MN 55442 | PHONE: 763-551-7600 | FAX: 763-551-7601